


## Exclusive Door Framing System ..

Now Make Your Own Doors .. Fast!



Quick, Easy On Site  
Tek Screw Assembly

All Cladding Edges  
are Fully Enclosed  
Within the Door Frame

Custom Rolled  
No Waste Material  
Strong, Lightweight  
Easily Transportable  
Fully Galvanised Sections  
No Welding of Door Frames  
Unlimited Cladding Options

Suitable for Assembly & Installation by the Home Handyman .. No Trade Skills Needed !

### Use Our Simple D.I.Y. Size Calculations ..

#### A DOOR HEIGHT

Underside of door track to  
floor level less 50mm

#### B DOOR WIDTH

Opening width plus 30mm (min) for  
overlap each end

#### EF4 PERIMETER FRAMING

Vertical Members (door sides) =

A

Horizontal Members (top & bottom) = B - 65mm

B

#### EB2 BACKING RAIL

Horizontal Cladding Braces =

B

Fix at 1800mm (max) spacings when used  
with 0.49 trimdek or similar profile claddings


Carriage Mounting Blocks - min. 100mm

Fix carriages 500mm (min) to 750mm (max) from door ends

Angle Braces - as required - approx 600mm

Door Push Rails - optional - approx 1000mm

CLADDING LENGTH A - 70mm




## How to Make Sliding Doors .. Quick & Easy

▶ Reduce labour costs - no welding !

▶ Reduce transport costs - transport in sections; no permits or wide loads !


... with Eltrak's Exclusive Door Framing System. The simple, economical way to make sliding doors to your exact size requirements.

### 1 Layout Components




Layout the lengths of perimeter door framing  
& backing rail supports ready for assembly as  
shown above.

### 2 Assemble Perimeter Frame




Position the perimeter frame sections, check  
height & width, and fasten with one tek screw in  
each corner. Square diagonals & fix with second  
tek screw.

### 3 Fit Support Braces




Position vertical push rails if required. Fit  
carriage mounting blocks & door guide blocks or  
full length bottom rail with one tek screw only.

### 4 Square Up & Fix Push Rails




Position top corner angle braces, then horizontal  
backing rail supports at approx 1800mm apart.  
Fix with one tek screw only each end.

### 5 Fit Carriages & Guides



Fit door carriages and door guides.  
Square all sides and diagonals, then fix with tek  
screws as required, frame corners first, then  
horizontal rails.

### 6 Turn Over & Fix Cladding



Turn over and check diagonals for square, tek  
screw each corner only. Fit cladding within the  
frame recess, tek screw to frame & horizontal  
braces.

Call Now ... 1300 668 311